



WHAT'S IN THE BOX













Detachable Type-C Cable



# KNOW YOUR PRODUCT









- 4 eXact Reset Function Switch 6 Backlit Brightness Adjustment

FN Multimedia Hotkeys LT 4 Level Variable Speed Keys

6 Light Effect Profiles

## Connect the cable Type-C plug to the keyboard and the USB plug to the computer.

2 Connect Notebook

## 1 Connect PC


INSTALLATION





(Note: Using a USB hub or extension cable to connect is not recommended.)





Full Keys Customization Gamer 😑 Full Keys Customization Gamer 🗐 Full Keys Customization Gamer 🖣

Full Keys / Independent Key Customization

### **EXACT RESET SYSTEM** When Hyper Z-Force Mode or Extreme X-Force Mode is enabled, the reset occurs at a much

\_\_\_\_\_\_



Deactivates the advanced reset modes.

0.3mm reset for ultra-fast speed and precision. X-Force Rapid Trigger 0.8mm reset for balanced speed and control. Disable Reset System

Shortcuts


shorter distance, allowing for quicker key presses and improving overall responsiveness.

This enhances reaction time and performance in various gaming scenarios.









### **FULL KEYBOARD AREA CUSTOMIZATION** Access LT Optical Travel Configuration setting by clicking 'Actuation Point' in the software.

Access settings for advanced software and hardware functions.



Configuration Example: Adjust the factory preset travel distances for LT-1, LT-2, and LT-3 to 2.6mm,

Locate 'Actuation Point' in the software interface. Customize the LT Key actuation points according

saved fi actuation points without needing extra drivers.

A: Select 2.6mm from 0.8mm for LT-1. B: Select 1.8mm from 1.1mm for LT-2 C: Select 1.6mm from 1.3mm for LT-3. Click (APPLY), then press the [III] button to switch

1.8mm, and 1.6mm respectively.


to the following steps:

between the three

**FULL-KEY INDEPENDENT CUSTOMIZATION** 

Access LT Optical Travel Configuration setting by clicking 'Actuation Point' in the software.

Configuration Example: Customize the LT-4 default actuation point template to create a highly personalized game profile. Go to  ${\bf Custom\,Area}$  to set the default actuation point template for the gaming category. Click (APPLY), then use the [ ] button to toggle



ALPHA PLAYER CUSTOMIZATION ( $\Box$ )Game Template Configuration Example: Customize the actuation points of the WASD

between the saved full-key independent variable speed actuation points without additional drivers Click on 'Advanced Setting' to access the actuation point editing platform and adjust the speed of both full-key and independent key actuation

points for the game template.



Default 7 Preset RGB Lighting Effects

0

(RGB)


3

Disable "Windows" Key \* The G LED in Solid Light Lighting Brightness +/-

Previous / Next Macro Profile

switch them by driver-free. Question What are the types of the actuation points settings? Answer With the software, customize the actuation points for all keys or individual keys, creating fully personalized profiles. Question Can I restore the factory default settings for the 4 LT speeds?

Question How to adjust the lighting brightness?



**TECH SPEC** Alpha Optical Variable Speed Switch **Adjustable Actuation Point** 23 Options 0.8mm~3.0mm 2-Stage RT Function R11: 0.3mm, R12: 0.8mm **Number of Keys** 87 Keys + 1 LT Variable Speed Key 100 Million Keystrokes **Switch Lifetime** Report Rate 1000 Hz Onboard Memory 4M **RGB Backlit Effect** 7 Lighting Effects



36.0 x 13.3 x 4.0 cm

981g (w/ cable), 911g (w/o cable)

Windows 7 / 8 / 8.1 / 10 / 11





www.Bloody.com Scan for E-Manual



**COMBINATION FN KEYS** 

Q & A

100% N-Key Rollover

Port Size

Weight

System

Question Can I switch the actuation points without software? (Answer) You may customize and save 4-level actuation points through the software, Answer Click the [Reset] Button in the software to restore the factory default settings.

